

TKOSROD1381K 2003-2017 DODGE VIPER FRONT AND REAR ADJUSTABLE SWAY BAR LINKS

TKOSROD1390K 2003-2017 LOWERED DODGE VIPER FRONT AND REAR ADJUSTABLE SWAY BAR LINKS

INSTALLATION INSTRUCTIONS
TKOMOTORSPORTS.COM

DISCLAIMER OF WARRANTY AND LIMITATION OF LIABILITY

Due to the intended use of high-performance products, TKO Motorsports LLC. products and each part thereof, are sold "AS IS" and with all faults. To the fullest extent allowed by law, TKO Motorsports LLC. makes NO written, oral, expressed, or implied statement of warranty or guarantee on any product or part sold. TKO Motorsports LLC. will not be liable for any direct, indirect, incidental, consequential, or special damages, including but not limited to, damage, injury, loss of life, loss of property or equipment, loss of profits or revenue, or claims from any individual or entity arising from the use of any TKO Motorsports LLC. product.

RACING IS A DANGEROUS ACTIVITY AND PURCHASERS OF TKO MOTORSPORTS LLC. PRODUCTS ACKNOWLEDGE THE INHERENT RISKS ASSOCIATED WITH RACING. TKO MOTORSPORTS LLC. MAKES NO REPRESENTATIONS THAT ITS PRODUCTS CAN REDUCE OR ELIMINATE ANY SUCH RISK. TKO Motorsports LLC. products are NOT FOR STREET, HIGHWAY, OR AIRCRAFT USE and are intended ONLY for race vehicles operated on closed-course facilities or racetracks with appropriate supervision of qualified technicians or mechanics to ensure that the safety needs of the race driver and others are met. TKO Motorsports LLC. products could be combined with other products or parts which may not be suitable and could adversely affect performance of other race parts or products in or on the vehicle. The user or installer shall determine the ultimate suitability and safety of the product for its intended use, and the user and installer assume all responsibility and risk in connection therewith.

Prior to any work being done it is recommended to use collision tape or some other protective cover in area where work will be done to minimize possibility of damage.

1. LOWERED VIPERS CORRECT PART IDENTIFICATION. If your 2003-2017 Dodge Viper is lowered 1-2 inches in the front and 1-1 ¾ inches in the rear, you should have ordered parts #TKOSROD1390K. To identify if you have the correct parts, measure the sway bar links (red anodized parts with hex machined into them) all (4) red anodized links should measure 1 ¾ long (only measure red anodized link). If your measurements are not 1 ¾ inch, please contact TKO Motorsports for assistance. See "Install Picture #1".

2. FACTORY RIDE HEIGHT 2003-2017 DODGE VIPER PART IDENTIFICATION. If your Dodge Viper is stock or factory ride height (not lowered) you should have ordered part #TKOSROD1381K. To identify if you have the correct parts, you can simply measure the red anodized links. The (2) front links should measure 2 ¾ inches long. The (2) rear links should measure 1 ¾ long. If your measurements are different, please contact TKO Motorsports for assistance.

3. It is easiest to install adjustable sway bar links while the car is sitting at ride height. A 4-post lift with integrated air hydraulic lift is recommended for installation.

4. Rear adjustable sway bar links installation. First, remove the factory rear sway bar links. Next, install the powder coated red sway bar extension bracket. The extension brackets are right and left and only fit one way. Install the clamp side of the extension bracket onto the sway bar loosely and line up the double sheer tabs on the bracket with the hole in the sway bar end where the factory sway bar link used to attach. Install flat head bolt through double sheer tabs and sway bar mounting hole (this can be a tight fit and may take some maneuvering to install flat head bolt). With flat head bolt installed, loosely start tightening clamp end of RED extension bracket to the sway bar. Consult SAE torque specifications publications for correct torque specification for all fasteners. With clamp end tight, now you can tighten and torque flat head fastener. Now, install adjustable sway bar link onto the red extension bracket using the fastener provided. Repeat process on other side.

5. Front adjustable sway bar links installation. Remove factory sway bar links. Now, install your new adjustable sway bar links.

Install Picture #1



TKOSROD1390K 2003-2017 LOWERED DODGE VIPER FRONT AND REAR ADJUSTABLE SWAY BAR LINKS
(complete kit shown)

Install Picture #2



TKOSROD1381K 03-17 DODGE VIPER FRT AND REAR ADJUSTABLE SWAY BAR LINKS

REAR SWAY BAR LINK WITH EXTENSION BRACKET INSTALLED ON REAR SWAY BAR



FRONT SWAY BAR LINK INSTALLED (*TKOSROD1390K 2003-2017 LOWERED DODGE VIPER SHOWN IN PIC*)

