

TKOSROD1282K 5TH GEN VIPER ACR ADVANCED DOWNFORCE DIFFUSER STRAKES

INSTALLATION INSTRUCTIONS
TKOMOTORSPORTS.COM

DISCLAIMER OF WARRANTY AND LIMITATION OF LIABILITY

Due to the intended use of high-performance products, TKO Motorsports LLC. products and each part thereof, are sold "AS IS" and with all faults. To the fullest extent allowed by law, TKO Motorsports LLC. makes NO written, oral, expressed, or implied statement of warranty or guarantee on any product or part sold. TKO Motorsports LLC. will not be liable for any direct, indirect, incidental, consequential, or special damages, including but not limited to, damage, injury, loss of life, loss of property or equipment, loss of profits or revenue, or claims from any individual or entity arising from the use of any TKO Motorsports LLC. product.

RACING IS A DANGEROUS ACTIVITY AND PURCHASERS OF TKO MOTORSPORTS LLC. PRODUCTS ACKNOWLEDGE THE INHERENT RISKS ASSOCIATED WITH RACING. TKO MOTORSPORTS LLC. MAKES NO REPRESENTATIONS THAT ITS PRODUCTS CAN REDUCE OR ELIMINATE ANY SUCH RISK. TKO Motorsports LLC. products are NOT FOR STREET, HIGHWAY, OR AIRCRAFT USE and are intended ONLY for race vehicles operated on closed-course facilities or racetracks with appropriate supervision of qualified technicians or mechanics to ensure that the safety needs of the race driver and others are met. TKO Motorsports LLC. products could be combined with other products or parts which may not be suitable and could adversely affect performance of other race parts or products in or on the vehicle. The user or installer shall determine the ultimate suitability and safety of the product for its intended use, and the user and installer assume all responsibility and risk in connection therewith.

STEP 1: Use an 8mm socket and remove all of the factory strakes from the carbon fiber diffuser. **Take note of each factory stake profile that is against the bottom of the car and the location of each factory stake that was removed from the diffuser and put the new advanced downforce strakes in the same locations.**

STEP 2: Position the advanced downforce strakes over the longer side of the peel rivets in the carbon fiber diffuser and use the included hardware and aero washers for mounting. The larger tear drop shaped aero washers are used in the aft. There are 2 positions for each stake. Use a 3mm allen wrench to tighten the bolts. Blue loctite is also recommended.



Longer side of the peel rivet through the stake



View from the driver's side



View from the passenger's side