

TKOSROD1459K 5th GEN VIPER REAR WHEEL WELL VENTS

INSTALLATION INSTRUCTIONS
TKOMOTORSPORTS.COM



DISCLAIMER OF WARRANTY AND LIMITATION OF LIABILITY

Due to the intended use of high-performance products, TKO Motorsports LLC. products and each part thereof, are sold "AS IS" and with all faults. To the fullest extent allowed by law, TKO Motorsports LLC. makes NO written, oral, expressed, or implied statement of warranty or guarantee on any product or part sold. TKO Motorsports LLC. will not be liable for any direct, indirect, incidental, consequential, or special damages, including but not limited to; damage, injury, loss of life, loss of property or equipment, loss of profits or revenue, or claims from any individual or entity arising from the use of any TKO Motorsports LLC. product.

RACING IS A DANGEROUS ACTIVITY AND PURCHASERS OF TKO MOTORSPORTS LLC. PRODUCTS ACKNOWLEDGE THE INHERENT RISKS ASSOCIATED WITH RACING. TKO MOTORSPORTS LLC. MAKES NO REPRESENTATIONS THAT ITS PRODUCTS CAN REDUCE OR ELIMINATE ANY SUCH RISK. TKO Motorsports LLC. products are NOT FOR STREET, HIGHWAY, OR AIRCRAFT USE and are intended ONLY for race vehicles operated on closed-course facilities or racetracks with appropriate supervision of qualified technicians or mechanics to ensure that the safety needs of the race driver and others are met. TKO Motorsports LLC. products could be combined with other products or parts which may not be suitable and could adversely affect performance of other race parts or products in or on the vehicle. The user or installer shall determine the ultimate suitability and safety of the product for its intended use, and the user and installer assume all responsibility and risk in connection therewith.

Prior to any work being done it is recommended to use collision tape or some other protective cover in area where work will be done to minimize possibility of damage.

STEP 1: Using the appropriate floor jack to lift the car, turn the handle clockwise. Move the handle up and down. Use the full stroke of the piston for greater speed. Support the vehicle with appropriate jack stands. Remove wheel from working space.

STEP 2: Use a T-30 to remove (8) bolts holding the factory plastic inner fender well panels. (see Figure 1, 2 & 3)



Figure 1



Figure 2



Figure 3

STEP 3: Insert new TKO vent panel and line up bolt holes. (see Figure 4 & 5)



Figure 4



Figure 5

STEP 4: Begin to thread (8) factory bolts into place. Only finger tighten the bolts to allow vent to move until all bolts are in place and lined up with holes. (see Figure 6 & 7)



Figure 6



Figure 7

STEP 5: Use T-30 to tighten bolts to approximately 4-5ft/lbs. or until snug. (see Figure 8, 9 & 10)



Figure 8



Figure 9



Figure 10

STEP 6: Put wheels back on and torque lug nuts to 110ft/lbs.

To lower the vehicle: lift the vehicle to remove the jack stands, ensuring that there are no persons or obstructions under the vehicle. Turn the handle counterclockwise.